Course Code: BPHT3004 Course Name: Pharmaceutical Engineering

**TOPIC:FLUID FLOW** 

Name of the Faculty: Dr. Shikha Yadav

Program Name:Pharmacy


**Course Code: BPHT3004** 

**Course Name: Pharmaceutical Engineering** 

# Manometer

- •It is an instrument used for measuring the pressure acting on column of fluid.
- it consist of U shaped tube in which different pressures acting in 2 arms of tube causes the liquid to reach diff height in 2 arms.
- the fluid which flows inside it is k/a manometric fluid

Course Code: BPHT3004 Course Name: Pharmaceutical Engineering



**Course Code: BPHT3004** 

**Course Name: Pharmaceutical Engineering** 

Name of the Faculty: Dr. Shikha Yadav

**Program Name:Pharmacy** 

**Course Code: BPHT3004** 

**Course Name: Pharmaceutical Engineering** 

### PIEZOMETER

- It is the simplest form of manometer. It measures gauge pressure only
- It consist of a vertical tube i.e. open at one end and attached to a container at other end. They are the devices used for measuring the difference of pressures between two points in a pipe or in two different pipes.
- It consists of a U-tube, containing a heavy liquid, Whose two ends are connected to the points whose difference of pressure is to be measured
- o It is suitable for measurement of small press. difference
- It is 2 of types: u- tube DM
  - : Inverted u-tube DM

Course Code: BPHT3004 Course Name: Pharmaceutical Engineering

#### **APPLICATION OF MANOMETER**

- ➤ Used in the maintenance of heating, ventilation, and air conditioning (HVAC) systems, low pressure pneumatic or gas systems.
- Construction of bridges, installing swimming pools and other engineering applications.
- ➤ Climate forecasting.
- ➤ Clinical applications like measuring blood pressure and in physiotherapy.
- ▶ Piezometers are used to measure the pressure in pipes where the liquid is in motion.

#### **Inclined TUBE MANOMETER**

It is a slant manometer

Inclination is done to improve the sensitivity

This manometer is used to measure very small pressure difference with increased accuracy

For ex- in air and gas installation, in this application the manometer is arranged with the indicating tube inclined

The angle of measuring arm is about 10degree

**Course Code: BPHT3004 Course Name: Pharmaceutical Engineering** P1-P2 = 9 RC PA - PB) 38n ~. measure small press. cliff. mead to magnify Pm some way. Pa - P6 = 9 R1 (Pa-P6) sPn x Risin x

**Course Code: BPHT3004** 

**Course Name: Pharmaceutical Engineering** 


# Principle of Pitot tube


According to Bernoulli's therom

Total energy at any point = Pressure energy + Potential energy + K. E

$$U_0 = C_0 \sqrt{2g \Delta H}$$
 .....  $\Delta H = Difference in pressure head$ 

 $\Delta H = U^2 / 2g$  ..... U = Velocity at point of incertion





Course Code: BPHT3004 Course Name: Pharmaceutical Engineering

### References

1: H., K AWAM UR A, H. & MATSUO, Y. 2001 Direct numerical simulation of a fully developed turbulent channel flow with respect to the Reynolds number dependence. J. Fluid. Eng. - T. 123, 382–393

2: R. A., KIM, J. & BROW NE, L. W. B. 1991 Some characteristics of small-scale turbulence in a turbulent duct flow. J. Fluid Mech. 233, 369–388

3: <a href="https://studylib.net/doc/8164236/ppt---manometer">https://studylib.net/doc/8164236/ppt---manometer</a>